

Freescale Semiconductor, Inc. Board Errata

Document Number: TWRLCDRGB\_ERRATA Rev. 0, 02/2015

# **TWR-LCD-RGB Board Errata**

by: Freescale Semiconductor, Inc.





### 1 Errata Title: Resistor R1 is unpopulated on the board

**Description:** Some TWR-LCD-RGB boards are built without R1 populated. This causes the I2C address line in the CRTouch firmware to be different than expected by the PEG touch drivers. Figure 1 show the affected resistor.




Figure 1. Affected R1 on TWR-LCD-RGB board

**Workaround:** The workaround is to populate the R1 location with a 0 Ohm surface mount resistor (603). A solder bridge between the two resistor pads is sufficient as well.

**Fix Plan:** The population option for the TWR-LCD-RGB has been updated to populate the R1 00hm resistor by default during assembly.



## **Revision history**

Table 3 describes the boards to which the errata in this document apply.

#### **Table 1. Revision of the Boards**

Board Assembly Rev.	Board Schematic Rev.	Board PN
Rev A	Rev E	TWR-LCD-RGB

### **Table 2. Document Revision History**

Revision number	Date	Substantial changes
1.0	02/2015	Initial release



How to Reach Us:

Home Page:

freescale.com

Web Support:

freescale.com/support

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: freescale.com/SalesTermsandConditions.

Freescale, the Freescale logo, and Kinetis are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Xtrinsic is trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. ARM and Cortex are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. mbed is a trademark of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved.

© 2015 Freescale Semiconductor, Inc.



Document Number: TWRLCDRGB\_ERRATA Rev. 0 02/2015

